

PLASTICOTE

I REFINISH OLDER UNITS

A. Preparation

1. Remove all plastic lenses.
2. Mask name plates.
3. Turn off butane.
4. Mask plastic vent covers.
5. Remove license plates.
6. Mask International Trim.

B. Application of Remover.

1. Spray from top of window down.
2. Flush with water hose.
3. Spray top.
4. Flush top.
5. Use pressure pot & Binks #7 gun.
6. Pressure
 - A. Line 35#
 - B. Pot 15#
7. Use water flush type remover
 - A. "Formula A"
 - B. "Best"

C. Preparation to apply new coat.

1. Wash entire unit with lacquer thinner.
2. Use soft cloth.
3. Wet a 3' x 3' area.
4. Dry with another cloth.
5. Change cloths when necessary.
6. Always wash with grain.

D. Application of new coat.

1. Mask windows.
2. Spray in vertical sections about 3' wide from center of top all the way to bottom.
3. Start at forward rib by door and move to right around trailer.
4. Material available at Airstream.
 - A. Do not thin.
 - B. Use pressure pot #7 Gun.
 - C. Spraying Pressures
 1. Line--95#
 2. Pot--10#
5. Dry--20 min. to 1 hour.